
Performance Technology 1

Bluetooth peripherals




BLEPAD

Blepad




The BLEPad is an Arduino compatible microcontroller development board based on the ATmega32U4 IC with Bluetooth 4.0. a.k.a. Bluetooth Low Energy (BLE), built in.

OUTPUT coloured more light light vibrate



We can switch on and off power at the digital pins programmatically.







We can switch on and off power at the digital pins programmatically.


What if we attached lights or buzzers or motors to the digital output pins?


OUTPUT: ADDING AN LED





How to switch on power at BLEPAD digital Output pin?






Conor has been working hard to make this easy for us.

Sending 0 will turn off the power at the pin Sending 255 will turn on the power at the pin


We Control The digital Output pin from PD



The digital output labelled D2 on the blepad


Sending 0 will turn off the power at the pin Sending 255 will turn on the power at the pin

Whats this going to allow us to do?



some more outputs

control a neopixel




control a buzzer

1 100 waveform no, duration s vibrate

INPUT

We can measure the electrical signal at digital and analog inputs This signal could be created by a button or a sensor



Handling Input from sensors connected to BLEPAD


you will receive a value between 0 and 1023. If 0V applied to pin you will receive 0. If 3.3V applied to pin you will receive 1023

```
r a_input_0 r a_input_1 r a_input_2 r a_input_3
```


if 3.3V applied to digital pin you will receive a 1 if 0V applied to digital pin you will receive a 0

```
r d_input_6 r d_input_9
```


Connect to BLEPAD using crocodile clips



CAUTION: SHORT CIRCUITS



Connect to BLEPAD using crocodile clips



SHORT CIRCUITS

- If the clip slips onto the pad beside it: BOOM
- If the clip slips forward and contacts part of the circuit:
 BOOM
- BE CAREFUL!!!! Read Lab instructions carefully.
- Check connections with Conor or me before connecting battery or USB. Connect Power last!!.
- Each BLEPAD = €20 and takes 1 month to arrive from China!

Final Project

- Start thinking about how you can use combinations of inputs and outputs to achieve your design aim.
- Where should the sensors and outputs be placed on the user?
- What might colour or buzz strength indicate?